



## AirShirz<sup>®</sup> Daily Cleaning and Lubrication

The AirShirz<sup>®</sup> drive roller and servo link should be greased daily to prevent excess wear. Begin by disconnecting the air line and removing the blade set.

Clean with Bettcher<sup>®</sup> Extra Heavy Duty Cleaner.

Next, open cover and push cylinder rod back into cylinder exposing grease fittings.

Hold tip of grease gun firmly on drive link grease fitting and apply grease until it comes out around drive roller.

Place tip of grease gun on grease hole in servo link and apply grease until it can be seen under servo link.

Wipe off any excess grease and replace blade set.

**Important:** Always use Whizard<sup>®</sup> Special Grease. Listed for use in federally inspected meat and poultry plants for incidental food contact. Lubricant specially developed for equipment requiring extended performance.

Grease Tube: Part # 100608

Grease Gun: Part # 113326

