





Quantum Flex® Air X350/X360






Quantum Flex® Air X440






Quantum Flex® Air X500/X505/ X500A





Quantum Flex® Air X564






Quantum Flex® Air X620/X625/ X620A






Quantum Flex® Air X750






Quantum Flex® Air X850/X880B & X880S






Quantum Flex® Air X1000 & X1500






Quantum Flex® Air X1300 & X1400





Quantum Flex® Air X1850 & X1880



Quantum Flex® Air Handle & Motor

Complete Power Unit Assembly

Large Gray #107055

Small Gray #16806

Small Blue #107016

Small Yellow #107422

Handle with O-Ring
Small #106807
Large #107057

Cap
#184286

Air Motor
Assembly
#107017

Gear Head
Assembly
#185935

Seal Kit
#184427

Seal Block
#184062

Muffler
#184388

Adapter Plate
Assembly #107019

Air Motor Assembly #107017

Upper Bearing
#185950

Upper Bearing Plate
Assembly #185948

Cylinder #106161

Rotor #185944

Vane Kit (Contains
5 Vanes) #185790

Retainer
#184049

Spacer
#184043

Lower Bearing Plate
Assembly #107018

Lower Bearing
#184046



Quantum Flex® Air Motor Maintenance Kit

Complete Maintenance Kit
#185975

Hex Wrench (Large Tool)
#184128

Hex Wrench (Small Tool) **#107325**

Gear Teeth Cap
#185977

Bearing Tool
#185978

Top Plate Removal
Clamp (2 required)
#184255

Rotor Removal
Punch **#184254**



Cup Assembly
#184246

Spanner Wrench
#184134

Base Assembly
#185976



Quantum Flex® Air Parts & Accessories

Optional and Replacement Parts




Quantum Flex® Air Parts & Accessories

Optional and Replacement Parts






Quantum Flex® TrimVac® 18 Head Assembly




Quantum Flex® TrimVac® 45 Head Assembly





Valve and Hose Assembly





Quick Start Valve and Hose Assembly

